



BTCK006 Hands-Free Car Kit

Dear Customer,
CONGRATULATIONS. The BTCK006 Bluetooth® Hands-Free Cell Phone Car Kit allows the driver to make voice calls hands-free via their Bluetooth® mobile phone. When used as described, the BTCK006 will give you years of dependable service in your car, truck, RV, or mini-van. We have taken numerous measures in quality control to ensure that your product arrives in top condition and will perform to your satisfaction. In the rare event that your BTCK006 Hands-free Bluetooth Car Kit contains a damaged or missing item, does not perform as specified, requires warranty service, **PLEASE FEEL FREE TO CONTACT US. Cellex Wireless PROMISES TO PROVIDE QUALITY GUARANTEE SERVICE FOR A YEAR.**

Features & Functions

NOTE: Read and completely understand this manual before operating a vehicle while using the BTCK006



IMPORTANT INFORMATION & PRODUCT MAINTENANCE

- Store in a cool, dry place; use clean soft cloth to clean the surface of Bluetooth® car kit.
- Do not expose to high or extremely low temperatures, or to dust.
- Do not open BTCK006 Non-professional maintenance may cause damage, and will void the warranty.
- Do not operate the BTCK006 roughly, e.g knocking, bumping.
- Do not short circuit the charging port of the BTCK006 ; a short circuit will cause damage to the battery.
- Use original accessories Only; any damage caused by using other accessories will void the warranty.

Operation

INSTALLATION

To install the BTCK006 attach to the visor of your vehicle using the clip on the rear of the unit.

CHARGING

Insert the mini USB connector of the charging adaptor into the mini USB charging port of BTCK006, then insert the 12 Volt adaptor end into the vehicle's cigarette lighter socket or 12 Volt Power Port. If the unit is ON, it will automatically shut OFF when you start charging, and the Red LED will come on to indicate the unit is charging. When the BTCK006 is fully charged, the Red LED will go off.

LOW BATTERY WARNING

When the BTCK006 battery is low, the Blue LED will be off, and the Red LED will flash, and the speaker will make a BEEP sound.

POWER ON AND OFF

Press and hold the Multi-Function Button for 3 seconds to turn the BTCK006 ON. There will be a short BEEP and the cancel button will flash blue. When the BTCK006 is in standby mode, press and hold the Multi-Function Button for 3 seconds to turn the unit off. You will hear a long BEEP, and both LED lights will turn off.

MULTI-FUNCTION BUTTON

POWER - Press and hold for 3 seconds.

PAIRING - Press and hold for 6 seconds

ANSWER A CALL - Press once

RE-DIAL - Press two times or more, depending on your phone's features.*

VOICE ACTIVATED DIALING - Press Once*

CALL TRANSFER - Press once to transfer to BTCK006

Press and hold for 3 seconds to transfer to cell phone

THREE WAY BUTTON

VOLUME - Move the 3-Way button to the right to increase, or move the 3-Way button to the left to decrease.

CALL WAITING* - With a call in progress you will hear 2 short tones, then:

1. Press and hold the 3-Way button to the right for 3 seconds to put the current call on hold and answer the waiting call.

Note: To cancel the second call and return to the "call on hold", press the cancel button once.

2. Press and hold the 3-Way button to the left for 3 seconds to cancel the current call and answer waiting call.

MUTE - Press and hold for 3 seconds to Mute or Unmute.

ENTER PHONE BOOK - Press Once

CHOOSE PHONE BOOKS - Move to Left or Right

CANCEL BUTTON

END CALL - Press Once

REJECT CALL - Press Once

EXIT PHONE BOOK - Press Once

PAIRING WITH A BLUETOOTH® ENABLED CELL PHONE

1. The BTCK006 and the Bluetooth® enabled cell phone should be within a distance of 3 feet (1 meter).

2. With the BTCK006 OFF, press the Multi-Function button for 6 seconds. The Red & Blue LEDs will flash alternately and the speaker will make a long BEEP sound.

3. The Bluetooth® cell phone will search for nearby Bluetooth® devices. The cell phone will display the "BTCK006" in the list of Bluetooth® devices. If you are using a "dongle" type Bluetooth® adaptor, follow the manufacturers' instructions for that device.

4. Select "BTCK006" to add this Bluetooth® device into the list of paired devices.

5. Enter in the PIN Code "0000" and your mobile phone will show that pairing is complete.

6. If pairing is successful, user will hear a long BEEP and the Blue LED will flash about every 3 seconds.

CALLER ID DISPLAY

The LCD will flash ON & OFF while displaying the phone number of the incoming call. On the first screen, the first ten digits will be displayed, the rest of the digits will be displayed on the last screen.

Operation

CALL LOG

1. Press the 3-Way button once to enter the Call Log menu. The three call log categories are: Missed Calls -> Dialed Calls -> Received Calls in that order.
2. Move the 3-Way button to the LEFT or RIGHT to navigate the three logs.
3. Press the 3-Way button once to enter the each log.
4. After you enter a Call Log, move the 3-Way button to the LEFT or RIGHT to navigate through the phone numbers. Press the Multi-Function Button to call the highlighted phone number.
5. Press the Cancel Button to quit the Call Log.

CALL LOG DISPLAY

Within the Call Logs, each number is preceded by a space to designate the order of the calls.

The first screen will show the first eight digits of the logged number. E.g. The number "0755-27973028" is displayed as follows: 075527973028

RECONNECT TO CELL

1. If the BTCK006 loses connection by moving out of operating distance of the paired cell phone, reconnect by moving it within the operating area and press the Multi-Function button once to reconnect to the cell phone.
2. If the BTCK006 is disconnected because of being powered off, it will connect automatically after powering on again.

STORAGE CONDITONS

Operating Temperature Range: 0°C to +50°C without loss of function
Storage Temperature Range: -20°C to +65°C without any damage to the
Humidity Range: 30%–90% humidity @ +60°C without loss of function

EARBUD

Insert the earbud's plug into the headphone jack on the side of the BTCK006
Use the Earbud for privacy or high ambient noise situations.

In order to get the excellent effect, please lift up "LCD Screen" to 30 degree.

*Note: Please refer to your cell phone's product user manual for Voice Dialing, Call & Redial functionality and settings.

ICONS



When the BTCK006 completes a Bluetooth® connection, the Bluetooth® icon will be on.



A solid Battery Power Level icon will display when the battery is full; One line on Battery Power Level icon will display when the battery is half full; only the battery frame will remain when the battery is discharged.



When opening the Call Logs, the Phonebook icon will be on.



When there is an incoming call, the Incoming Call icon will be on while the backlit LCD flashes



When entering the Received Call Log, the Received Call icon on the LCD and the Phonebook icon will be on.



The Missed Call icon will be on when a call is missed and until that call is acknowledged.



When entering the Dialed phone numbers in the Phonebook, the Outgoing Call icon on the LCD and the Phonebook icon will be on.



When checking a phone number in the Missed Call Log, the Missed Call icon and the Phonebook icon will be on.



Caution: The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These Limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference, will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.